



Gateway®

10" Tablet

Quick Start Guide

Model: GATM11033

Start Here

To Power On

Press and hold the power button to power on. Device will boot up automatically.

To Power Off

During use, press and hold the power button for about 5 seconds to power off, a system window will appear. Select "power off" followed by "ok." Device will shut down.

Sleep Mode


Tap the Power button to enter/exit sleep mode.

NOTE:

▲ Please make sure to fully charge your device before powering on.

▲ For Spanish users, go to "Settings" - "System" - "Language & input", then go to "Language" to enter "Language preferences", then click "Add a language", then choose "Español", then choose your regions, then, on "Language preferences" interface, press and move your language to the first place.

Exterior Features



- | | |
|-----------------|-----------------|
| 1 Front Camera | 7 Volume up |
| 2 Touchscreen | 8 Volume down |
| 3 USB Type-C | 9 Power Button |
| 4 Micro SD Slot | 10 Reset Button |
| 5 Earphone port | 11 Speaker |
| 6 Rear Camera | |

What's in the box

- | | |
|----------------------|---------------------|
| 1 Tablet | 4 Quick Start Guide |
| 2 USB to USB-C Cable | 5 Warranty Book |
| 3 Wall Adapter | |

Caution: The AC adapter included with your device was specifically designed and approved for your model. Utilization of an after-market adapter may damage either your device or other devices connected to it. If damage is determined to have been caused by utilization of an unauthorized power supply, it will not be protected under warranty.

For full user manual, please visit www.gatewayusa.com/support.html

Gateway and the Gateway logo are the registered trademarks of Acer Inc. and are used under license from Acer America Corporation.

www.gatewayusa.com | Customer Service: (877) 777-0649